



VTech Record and Learn KidiStudio Black Piano Keys Replacement

We will be replacing the black piano keys

Written By: Shaina Carbonel



INTRODUCTION

Showing how to replace the black piano keys on the VTech Record and Learn KidiStudio.



TOOLS:

- [Phillips #2 Screwdriver](#) (1)



PARTS:


- [Replacement Black Piano Keys](#) (1)

Step 1 — Black Piano Keys




- Unscrew 11 PH2 screws (7 mm).
 - Remove the black plastic backing.
- ⚠ Remove the batteries from the toy before beginning replacement of the piano keys.**

Step 2




- Near the bottom of the device, unscrew 5 PH2 screws (7 mm) on the electric board.
- Pull back the electrical board.

Step 3



- Unscrew 6 PH2 screws (11 mm) on the black bar holding the keys on the device.

Step 4



- Pull out the black piano keys and replace with the new piano key part.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-28 07:52:35 PM.